## ALL PURPOSE ANCHORS



concrete accessories

## **ALL PURPOSE ANCHORS**

Lifting Anchor for retaining walls.

CONAC AP (All Purpose) Anchors are intended for use in a variety of products where an inexpensive anchor, with modest capacities, is needed.

AP Anchors are used in tension and normally project out of the product for ease of use.



ITEM #	WIRE DIAMETER	WIDTH	LENGTH	WEIGHT	SWL (LBS)
AP-1/4x6	1/4"	2-7/8"	6"	0.175 LB	1600
AP-3/8x6-3/4	3/8"	2-1/2"	6-3/4"	0.51 LB	4200
AP-7/16x9	7/16"	3-7/8"	9"	0.975 LB	7500

Note: SWL provides a factor of safety of approximately 4:1 in 2,500 psi normal weight concrete.



CALL US TOLL FREE 1-800-336-2598 www.conacweb.com